

IMPORTANT NOTICE

Upper/Lower Case Driver for Cassette Systems (ULCBAS) 26-1104

Some BASIC programs may over-write part of the ULCBAS software, causing the Computer to “freeze up” or revert back to the initialization dialog.

To prevent this from happening, we suggest you **always** use the following procedure for loading ULCBAS (ignore steps 1, 2 and 3 on page 3 of your ULCBAS Owner's Manual).

1. Reset the Computer, and prepare the recorder to play the ULCBAS side of the tape.
2. Type in the following instructions (the underlined material is provided by the computer – do not type it in):

≥ SYSTEM **ENTER**
*? ULCBAS **ENTER**

3. The Computer will now load the tape. After the load is complete, type:

*? **BREAK**
READY

In the next line, the value of “xxx” depends on how much RAM is in your system.

RAM	Value for “xxx”
16K	125
32K	189
48K	253

Continue, using the appropriate value for “xxx”.

≥ POKE 28829, 242 : POKE 28830 ,xxx **ENTER**
≥ SYSTEM **ENTER**
*? / **ENTER**

4. When “READY” returns, you can begin by using the upper/lower case capability.

Thank You
Radio Shack Technical Publications
Fort Worth, Texas 76012